



PROCEDURE TO INSTALL TRANSITION

1. LAY OUT POINTS A, B, E, & F.
2. USE POINTS (Δ) B & E TO DETERMINE A STRAIGHT LINE AND MARK C & D.
3. MARK G & H BY MEASURING IN 190 mm (7 1/2") [FOR 27 m (90') & 18 m (60') TRANSITIONS] PERPENDICULAR TO LINES A-B AND E-F.
4. FORM CURVES A-G-C AND D-H-F.
5. STRIPE

NOTE:

FOR 18 m (60') TRANSITION, USE FIGURES IN PARENTHESES SHOWN ON DIAGRAM AND PROCEED WITH STEPS 1 THROUGH 5.

CITY OF PASADENA - PUBLIC WORKS & TRANSPORTATION DEPARTMENT

DRAWN BY:
M. MOJICA

CHECKED BY:
D. ORTEGA

SUBMITTED BY:
C. HERNANDEZ

LAYOUT - 3 m (10') WIDE TURN BAY TRANSITION

APPROVED BY:
Bahy J...

TRANSPORTATION ADMINISTRATOR RITE NO. 1820 EXPIRES JUNE 30, 2005

6/4/01
DATE

REVISION: 1
UNITS: DUAL

STANDARD PLAN:

S-714

SHEET 1 OF 1
3714-1-REV1.DWG 3/24/01